## SWD & MVP

**End termination installation instructions** 

## Peel Back Fabric:

Peel back the fabric about 4 - 5 inches. Cut and remove the core at a 90 degree angle in between the dimples.



## **Pold Fabric:**

Fold the excess fabric over the core toward the flat side of the product.



# **3** Hold fabric in place:

Hold fabric flap in place flat against core.



#### 4 Tape:

Using **J-Tape**, secure flap to the core by taping completely around product.



info@j-drain.com

www.j-drain.com

JDR Enterprises, Inc.

292 S. Main St., Suite 200 Alpharetta, GA 30009 (800) 843-7569 (770) 442-1461 Fax: (770) 664-7951